

ASTORINO

Operation Manual



ASTORINO Operation Manual

Preface

This manual describes the handling of the 6-axis robot "astorino" and the associated "astorino" software. This is an original documents and is not translated.

The ASTORINO is a learning robot specially developed for educational institutions. Pupils and students can use the ASTORINO to learn robot-assisted automation of industrial processes in practice.

This manual is valid from firmware version 3.9.0 and astorino software version 1.9.8 and B – version of the robot.

ASTORINO Operation Manual

1. The "astorino" software included with the ASTORINO is licensed for use with this robot only and may not be used, copied or distributed in any other environment.
2. Kawasaki shall not be liable for any accidents, damages, and/or problems caused by improper use of the ASTORINO robot.
3. Kawasaki reserves the right to change, revise, or update this manual without prior notice.
4. This manual may not be reprinted or copied in whole or in part without prior written permission from Kawasaki.
5. Keep this manual in a safe place and within easy reach so that it can be used at any time. If the manual is lost or seriously damaged, contact Kawasaki.

Copyright © 2025 by KAWASAKI Robotics GmbH.

All rights reserved.

Symbols

Items that require special attention in this manual are marked with the following symbols.

Ensure proper operation of the robot and prevent injury or property damage by following the safety instructions in the boxes with these symbols.

WARNING

Failure to observe the specified contents could possibly result in injury or, in the worst case, death.

[ATTENTION]

Identifies precautions regarding robot specifications, handling, teaching, operation, and maintenance.

WARNING

- 1. The accuracy and effectiveness of the diagrams, procedures and explanations in this manual cannot be confirmed with absolute certainty. Should any unexplained problems occur, contact Kawasaki Robotics GmbH at the above address.**
- 2. To ensure that all work is performed safely, read and understand this manual. In addition, refer to all applicable laws, regulations, and related materials, as well as the safety statements described in each chapter. Prepare appropriate safety measures and procedures for actual work.**

Paraphrases

The following formatting rules are used in this manual:

- For a particular keystroke, the respective key is enclosed in angle brackets, e.g. <F1> or <Enter>.
- For the button of a dialog box or the toolbar, the button name is enclosed in square brackets, e.g. [Ok] or [Reset].
- Selectable fields are marked with a square box . If selected a check mark is shown inside the symbol .

Change log:

| Date | Change Description |
|------------|--|
| 2024/09/06 | Create a changelog Update some screenshots Added dedicated signals descriptions Added External Control chapter |
| 2024/12/18 | Added section of recommended students age |
| 2025/01/28 | Added more information about intended use |
| 2025/03/03 | Added FAQ and Spare parts list Added document number Added 3d printing parameters Added nameplate and serial number description |
| 2025/03/26 | Added Light indicators Added compressed air warning Added Emergency Stop section |
| 2025/09/02 | Added Modbus settings section Added Clamp and JT7 section Changed JOG, Sys. Settings tabs pictures Added GripBox settings information |

ASTORINO Operation Manual

List of contents

| | |
|---|----|
| Preface | I |
| Symbols..... | 1 |
| Paraphrases..... | 2 |
| Change log:..... | 2 |
| List of contents | 3 |
| 1 Nomenclature in this manual | 7 |
| 2 Overview of ASTORINO..... | 8 |
| 3 Intended operation | 8 |
| 4 Recommended age of students | 9 |
| 5 Technical specifications..... | 10 |
| 6 Robot package contents..... | 11 |
| 7 Range of motion..... | 12 |
| 8 Mounting dimensions..... | 13 |
| 9 Installation points for accessories..... | 14 |
| 10 Payload chart..... | 17 |
| 11 Electrical connections | 18 |
| 12 Light indicator..... | 19 |
| 13 Safety notes | 20 |
| 14 Unboxing and starting-up..... | 21 |
| 14.1 Connecting accessories | 21 |
| 14.2 System Requirements..... | 23 |
| 14.3 Driver installation..... | 23 |
| 14.4 Installing the astorino Software..... | 24 |
| 14.5 Making the astorino ready for operation..... | 25 |
| 15 EMERGENCY STOP | 28 |
| 15.1 EMERGENCY STOP release..... | 28 |
| 15.2 Restart after EMERGENCY STOP | 29 |
| 16 Coordinate systems..... | 30 |
| 16.1 The BASE coordinate system..... | 30 |
| 16.2 The JOINT coordinate system..... | 31 |
| 17 Robot operation modes..... | 32 |
| 17.1 Teach Mode..... | 32 |
| 17.2 Repeat Mode | 32 |
| 18 Manual operation of robot | 33 |
| 18.1 JOINT..... | 33 |

ASTORINO Operation Manual

| | | |
|--------|-------------------------------------|----|
| 18.2 | BASE | 34 |
| 18.3 | TOOL | 35 |
| 18.4 | WORK | 37 |
| 19 | ROBOT MOVEMENT | 38 |
| 19.1 | LINEAR INTERPOLATION | 39 |
| 19.2 | JOINT INTERPOLATION | 39 |
| 19.3 | CIRCULAR INTERPOLATION | 40 |
| 20 | astorino Software | 41 |
| 20.1 | Basic information | 41 |
| 20.2 | Visualization Window | 42 |
| 20.2.1 | Visualization window handling | 43 |
| 20.2.2 | Object types | 43 |
| 20.2.3 | Simple Shape Generator | 44 |
| 20.2.4 | Objects modify menu | 46 |
| 20.2.5 | GripBox settings | 46 |
| 20.2.6 | Visualization settings menu | 48 |
| 20.2.7 | Working Space visualization | 49 |
| 20.2.8 | Working Range visualization | 49 |
| 20.3 | Status | 50 |
| 20.4 | Control | 51 |
| 20.4.1 | Motors (ON/OFF) | 52 |
| 20.4.2 | Control | 54 |
| 20.4.3 | Connection | 54 |
| 20.5 | JOG | 55 |
| 20.5.1 | Jogging | 58 |
| 20.5.2 | Current Position | 60 |
| 20.5.3 | STEP - TEACH | 60 |
| 20.5.4 | Teach Point | 61 |
| 20.5.5 | Execute Motion Command | 61 |
| 20.6 | Points | 62 |
| 20.7 | Home/Tool | 63 |
| 20.7.1 | Home | 63 |
| 20.7.2 | Tool | 64 |
| 20.7.3 | TOOL WIZARD | 64 |
| 20.7.4 | WORK | 65 |
| 20.7.5 | WORK WIZARD | 66 |

ASTORINO Operation Manual

| | | |
|------------|--|----|
| 20.7.6 | Power off position | 66 |
| 20.7.7 | Zeroing order | 67 |
| 20.8 | Moving Area | 68 |
| 20.8.1 | XYZ Limits | 68 |
| 20.8.2 | Range | 69 |
| 20.8.3 | Working Space | 70 |
| 20.9 | Programs | 71 |
| 20.10 | System Setting | 74 |
| 20.11 | I/O | 75 |
| 20.12 | Terminal | 75 |
| 20.12.1 | Status und configuration section | 76 |
| 20.12.1.1 | Clamp/JT7 | 76 |
| 20.12.1.2 | MODBUS I/O | 77 |
| 20.12.1.3 | Clamp | 77 |
| 20.12.1.4 | Dedicated IO | 78 |
| 20.12.1.5 | Collision detection (B version of the robot) | 79 |
| 20.12.1.6 | Conveyor | 79 |
| 20.12.1.7 | Ethernet | 80 |
| 20.12.1.8 | Calibration | 80 |
| 20.12.1.9 | Firmware | 81 |
| 20.12.1.10 | Modbus Set | 81 |
| 20.13 | About | 83 |
| 20.14 | Firmware Update | 84 |
| 20.14.1 | Basic information | 84 |
| 20.14.2 | Update procedure | 85 |
| 20.15 | Update fail recovery | 88 |
| 20.16 | AS-language | 89 |
| 20.17 | Programming | 93 |
| 20.17.1 | Creating a new program | 93 |
| 20.17.2 | Write a program | 94 |
| 20.17.3 | Loading a program onto the robot | 94 |
| 20.17.4 | Running currently selected line | 95 |
| 20.17.5 | Running a program | 96 |
| 20.17.6 | Stopping a program | 96 |
| 21 | Example programs | 98 |
| 21.1 | Pick & Place – Palletization example | 98 |

ASTORINO Operation Manual

| | | |
|--------|--|-----|
| 21.2 | I/O example program | 100 |
| 21.3 | Serial communication example program | 100 |
| 22 | Tool Data | 102 |
| 22.1 | Tool data from known dimensions..... | 102 |
| 22.2 | Automatic Tool (Coordinates Data) Registration | 104 |
| 22.2.1 | Overview of Automatic Tool Registration Function | 104 |
| 22.2.2 | Required Data for Automatic Tool Coordinates Registration..... | 105 |
| 22.2.3 | Teaching the Four Base Poses..... | 105 |
| 22.2.4 | Teaching the Six Base Poses..... | 108 |
| 23 | Automatic WORK (Coordinates Data) Registration | 112 |
| 23.1.1 | Teaching the three base points | 112 |
| 24 | Auto-calibration of collision detection | 114 |
| 25 | I/O – 3,3V | 115 |
| 26 | ARM INPUTS/OUTPUTS | 117 |
| 27 | MODBUS TCP | 118 |
| 27.1 | Modbus network operating modes..... | 118 |
| 27.2 | Modbus object types in astorino robot | 119 |
| 27.3 | Configuration of the Ethernet port..... | 120 |
| 27.4 | ASTRAADA HMI panel – example | 121 |
| 27.5 | Using Modbus registers to read/write numeric data..... | 127 |
| 28 | External Control and RTC | 127 |
| 29 | Calibration..... | 128 |
| 30 | FAQ/Troubleshooting and spare parts..... | 128 |
| 31 | Manufacturer information | 129 |
| | Appendix 1 – Default zeroing procedure | 130 |
| | Appendix 2 – 3D printing parameters..... | 132 |
| | Appendix 3 – Name plate and serial number | 133 |
| | Appendix 4 – PET-G material | 134 |
| | Appendix 5 – PNP wiring | 135 |
| | Appendix 6 – Teensy 4.1 | 136 |

1 Nomenclature in this manual

The author of the manual tries to use generally valid terminology while achieving the greatest possible logical sense. Unfortunately, it must be noted that the terminology is reversed depending on the point of view when considering one and the same topic. Also it is to be stated that in the course of the computer and software history terminologies developed in different way. One will find therefore in a modern manual no terminologies, which always satisfy 100% each expert opinion.

ASTORINO Operation Manual

2 Overview of ASTORINO

The ASTORINO is a 6-axis learning robot developed specifically for educational institutions such as schools and universities. The robot design is based to be 3D printed with PET-G filament.

Damaged parts can be reproduced by the user using a compatible 3D printer with recommended print setting – see APPENDIX 2.

ATTENTION!

Astor and Kawasaki Robotics do not take responsibility for robot parts 3D printed by user!

<https://ftp.kawasakirobot.de/Software/Astorino/>

Just like Kawasaki's industrial Robots the ASTORINO is programmed using AS language. Providing transferable programing skills from the classroom to real industrial applications.

3 Intended operation

The astorino robots are designed to move and position small loads or objects. astorino robots are meant to be educational robots, working in controlled environment of laboratories as training machines.

According to the Machine Directive 2006/42/EC astorino robot is a partly completed machinery.

Furthermore, if are intended to be incorporated into or assembled with other machinery or other incomplete machinery or equipment in order to form a machine along with them in accordance with Machinery Directive 2006/42/EC.

A risk assessment in accordance with the safety regulations applicable in your country is necessary prior to each installation and use of the robot. Be sure to follow the safety instructions in Safety Manual.

Astorino robot is intended for educational, and research and development purposes, i.e.:

- learning robotics,
- research and development in robotics,

ASTORINO Operation Manual

- simulation and prototyping of complete industrial scenarios such as "Pick & Place" (take an object to move it), "Pick & Pack" (take an object to insert it into a packaging) etc.
- hardware application: connect and control the robot with sensors and external actuators in order to simulate an application, while respecting the conditions defined in this instruction manual,

The operations below do not comply with the uses set by Kawasaki Robotics and Astor. They include:

- use as a children's toy,
- use for industrial tasks;
- use for handling inappropriate objects (with unsuitable grippers, objects whose mass is greater than the maximum authorized load),
- use that exceeds the stated specifications,

Any use of the robot and its ecosystem that does not comply with the uses initially intended by Kawasaki Robotics and Astor must be expressly authorized by Kawasaki Robotics and Astor.

4 Recommended age of students

Astorino was designed to be used in technical schools, high schools/college and universities. Recommended minimal age of student therefore is 16 years old. Youngs at lower age might find it difficult to use and program the robot safely.


ASTORINO Operation Manual

5 Technical specifications


| Characteristics | ASTORINO | |
|-----------------------------|---------------------------------|----------------------|
| Type | 6-axis robot | |
| Max. lifting capacity | 1 kg | |
| Number of axes | 6 | |
| Max. range | 578 mm | |
| Repeatability | ±0.2 mm | |
| Motion range | Axis 1 (JT1) ±158° | |
| | Axis 2 (JT2) -90°÷127° | |
| | Axis 3 (JT3) -168°÷0° | |
| | Axis 4 (JT4) ±240° | |
| | Axis 5 (JT5) ±120° | |
| | Axis 6 (JT6) ±360° | |
| Max. single axis speed | Axis 1 (JT1) 38°/s | |
| | Axis 2 (JT2) 26°/s | |
| | Axis 3 (JT3) 26°/s | |
| | Axis 4 (JT4) 67.5°/s | |
| | Axis 5 (JT5) 67.5°/s | |
| | Axis 6 (JT6) 128.5°/s | |
| Allowable moment | Axis 4 (JT4) 6.2 Nm | |
| | Axis 5 (JT5) 1.45 Nm | |
| | Axis 6 (JT6) 1.1 Nm | |
| Working environment | Temperature 15-35°C | |
| | Humidity 35-60% | |
| Controller | Teensy 4.1 | |
| Inputs/Outputs | 8/8 (PNP 8 mA, NPN 15 mA) | |
| | 2/2 (24V PNP on the JT3) | |
| Max. power consumption | 144 W | |
| Average power consumption | 65 W | |
| Power supply | 100-240 V, 50-60 Hz | |
| Max. emitted acoustic pres. | < 85 dB(A) | |
| Weight | 11 kg | |
| Mounting position | Floor | |
| Material | PET-G | |
| Colour | Black | |
| Communication | MODBUS TCP, TCP/IP, UDP, SERIAL | |
| Collision detection | Accelerometer | |
| Power loss safety | Brakes on JT2 and JT3 | |
| Options | 24V I/O-module | 8 × Inputs / Outputs |
| | 7 th axis | Linear Track |
| | Vision system | OpenMV |
| | Belt tracking | Max. 2 Encoder |

ASTORINO Operation Manual


6 Robot package contents



astorino Robot





External emergency stop
in pushbutton housing





24V/DC power supply, USB cable
and USB stick

7 Range of motion




ASTORINO Operation Manual


8 Mounting dimensions





9 Installation points for accessories



ASTORINO Operation Manual




ASTORINO Operation Manual




ASTORINO Operation Manual

10 Payload chart




11 Electrical connections



| | |
|-----|--|
| 1. | M8 socket 4-Pin – external emergency stop (E-Stop) |
| 2. | <i>Safety Fence (OPTION)</i> |
| 3. | <i>Pressure inlet Ø4.0 mm</i> |
| 4. | USB-B port |
| 5. | <i>OPTION 2 (Encoder 2 – Conveyor 2/JT7)</i> |
| 6. | <i>OPTION 1 (Encoder 1 – Conveyor 1)</i> |
| 7. | <i>Vision-System/Serial-Communication</i> |
| 8. | Power ON/OFF switch |
| 9. | Ethernet port (RJ45) |
| 10. | Power supply |

12 Light indicator



| | |
|---|---|
| 1 | Green LED - Power ON (5V indicator for logic circuit) |
| 2 | <i>Red LED - Error</i> |

13 Safety notes

[ATTENTION]

Always pay attention to the personal safety of the user and other persons when operating the robot arm!

- In its basic version, the robot does not have any safety-relevant components for the robot workstation. Depending on the target application, such components may be required. The basic version of the robot is equipped with an external emergency stop button (8), which must be connected before the first start-up!
- The robot controller contains a 24V power supply unit that must be supplied with mains voltage (100/230V). Observe the label on the power supply unit. Only qualified personnel may connect the power supply unit to the mains and put it into operation.
- Work on the electronic components of the robot should only be carried out by qualified personnel. Observe the applicable guidelines for electrostatic discharge (ESD).
- Always disconnect the robot from the power supply (100/230V) when working on the robot base or on electronic components connected to the robot controller.
- Hot plugging is prohibited! This could cause permanent damage to the motor modules. Do not install or remove any modules or connectors (e.g. emergency stop buttons, DIO modules, motor connectors) while the power supply is switched on.
- The robot arm must stand on a stable surface and be screwed down or otherwise secured
- Use and store the system only in a dry and clean place. The recommended room temperature is 15° to 32°C.
- Please note that:
 - The robot can only be used under the proper technical conditions, for its intended uses, while taking into consideration potential hazards;
 - the robot must be used in accordance with the instructions in this manual;
 - Kawasaki Robotics or Astor is not liable for any modification made to the software or physical characteristics of the robot by the user.
 - We shall not be liable for any damage caused if it is used in a way that does not comply with the instructions given in this manual.

14 Unboxing and starting-up

ATTENTION!

Before installation read chapter 10. Installation instructions in Safety Manual.

Once the robot is removed from the packaging, secure it to a solid surface.

⚠ WARNING

Authorized personnel must be approved by Astor or Kawasaki Robotics company or their partners. Authorized personnel should also be trained how to deal with electronic equipment and must have all necessary legislations to work with electric equipment.

14.1 Connecting accessories

⚠ WARNING

Do not unplug pressure inlet without bleeding off pressure source first!



- Mount the robot on a suitable base, table or metal plate.
- Connect the power supply unit and the external emergency stop button to the connections on the robot base.

ASTORINO Operation Manual

Turn on the robot by pressing the illuminated button.



- Connect the USB cable to the USB-B port of the robot base, then connect it to a computer.



ASTORINO Operation Manual

14.2 System Requirements

Before installing astorino software, ensure that the computer meets the following hardware and software requirements.


| Part | Requirements |
|------------------|---|
| CPU | 2.0 Ghz or faster processor |
| Memory | 4 GB minimum |
| Disk | 100 MB free space |
| Graphics card | Any |
| Display settings | 1280 x 720 pixels minimum resolution, 100 % display scaling recommended |
| Mouse | Three-button mouse |

| System | Version |
|---------|-------------------|
| Windows | 7, 8, 8.1, 10, 11 |

14.3 Driver installation

The required drivers install automatically since Windows 8. After successful installation, the robot will appear in the Device Manager as <USB Controller>. If using Windows 7 install the drivers before connecting the robot to the PC (downloaded from Kawasaki FTP server or from USB stick).


Open device manager via <**Windows + R**> \Rightarrow devmgmt.msc or by clicking the icon in the selection menu via <**Windows + X**>.




ASTORINO Operation Manual

14.4 Installing the astorino Software


Run astorino_x.x.x.exe



Confirm or specify installation directory




Read and accept the license agreement




ASTORINO Operation Manual

Start the installation




14.5 Making the astorino ready for operation

- Open the astorino software.
- The COM port to which the robot is connected will automatically appear in the drop-down list in the [Control]-menu **Connection** area.



ASTORINO Operation Manual

- Click [Reset], when this button is red (check the emergency stop button)




- The motors are powered by clicking on the gray [MOTOR ON] button.
- Click on the yellow flashing field [Zeroing] to perform the zeroing process.

Zeroing must be performed each time the robot is powered or the motors are disabled.

- Make sure that the robot wont collide with any devices while zeroing is performed! Default zeroing procedure is described in the appendix of this document.

ASTORINO Operation Manual



- When zeroing is complete, the robot stops at 0 degrees on each axis (with default zeroing procedure) and is ready for programming.




ATTENTION!

The upright position is the standard position of the arm after the zeroing process is complete. If the settings of the reset procedure have been changed, the end position may be different!


ASTORINO Operation Manual

15 EMERGENCY STOP

In case emergency press EMERGENCY stop BUTTON




EMERGENCY STOP will immediately stop the robot and turn off motor power.



15.1 EMERGENCY STOP release


To release the emergency stop twist the EMERGENCY STOP button and then press RESET button



ASTORINO Operation Manual

15.2 Restart after EMERGENCY STOP


In case when robot is stopped in a different position than set Power Off Position it is recommended to manually move (by hand) the robot to safe – start Zeroing position




To release the JT2 and JT3 brakes please follow the Maintenance Manual.

16 Coordinate systems

16.1 The BASE coordinate system




The left hand rule helps to remember the axis directions:



16.2 The JOINT coordinate system

The individual joints are numbered in ascending order, starting from the robot base. JT stands for joint.




17 Robot operation modes

17.1 Teach Mode

This mode enables manual operations of the robot like moving, teaching. In this mode the maximum speed is limited to 60 mm/s and 12 deg/s for each axis.

Teaching is defined as programming the robot to do the required tasks and recording the positions data.

Robot is in the Teach Mode when [REPEAT/TEACH] switch's background is blue.



In Teach Mode when Safety Fence input is High robot operations are not restricted.

17.2 Repeat Mode

Repeat operations plays back the contents of a program that was taught to the robot. In this mode speeds are not restricted and robot can move at maximum of 250 mm/s.

Robot is in the Repeat Mode when [REPEAT/TEACH] switch's background is green.









In Repeat Mode when Safety Fence input is High robot operations are restricted.

ASTORINO Operation Manual

18 Manual operation of robot

In Teach mode based on the currently selected motion mode (BASE, JOINT, TOOL) manual movement of the robot arm is possible.


18.1 JOINT

| | |
|---|--|
| JT1: Left and right rotation of an arm  | JT4: Rotation of a wrist axis (1)  |
| JT2: Back and forth motion of an arm  | JT5: Rotation of a wrist axis (2)  |
| JT3: Up and down motion of an arm  | JT6: Rotation of a wrist axis (3)  |


ASTORINO Operation Manual

18.2 BASE


X: Motion parallel to base X coordinate
(wrist orientation is constant)




RX: Rotation around base X coordinate
(TCP does not move)




Y: Motion parallel to base Y coordinate
(wrist orientation is constant)




RY: Rotation around base Y coordinate
(TCP does not move)



Z: Motion parallel to base Z coordinate
(wrist orientation is constant)




RZ: Rotation around base Z coordinate
(TCP does not move)




ASTORINO Operation Manual

18.3 TOOL

Tool coordinate system is defined on the tool which is installed in JT6. Operations based on this tool coordinate system will differ in motion direction depending on the coordinates transformation to the null-tool coordinates. Tool coordinates also change when wrist orientation changes as shown in figures below, even though only the forearm moves without moving the wrist axes.




Arm at different location and orientation




ASTORINO Operation Manual


x: Motion parallel to tool X coordinate
(wrist orientation is constant)




rx: Rotation around tool X coordinate
(TCP does not move)




y: Motion parallel to tool Y coordinate
(wrist orientation is constant)




ry: Rotation around tool Y coordinate
(TCP does not move)



z: Motion parallel to tool Z coordinate
(wrist orientation is constant)




rz: Rotation around tool Z coordinate
(TCP does not move)




ASTORINO Operation Manual

18.4 WORK

WORK coordinate system is defined on any plane in space that is in robots motion range. Operations based on this WORK coordinate system will differ in motion direction depending on the coordinates transformation to the BASE coordinates.




Arm at different location of WORK coordinate system



19 ROBOT MOVEMENT

Acceleration for the second segment begins after the execution of the first segment is completed, when the current position is at the target point. The slope of the speed rise is determined by the ACCEL parameter and the braking edge by the DECEL parameter.



Astorino robot can move in three different ways. These ways are called interpolations. We can distinguish:

- Linear interpolation
- Joint interpolation
- Circular interpolation

In an anthropomorphic robot arms (6 axis) there exists some positions that are called singularities. A singular position where problem of structurally uncontrollable position might occur exists when for example JT4 and JT6 are parallel to each other, or JT1 and JT6 are parallel to each other. These configurations return multiple mathematical solution of inverse kinematics and therefore the motion through these points might be unpredictable and introduce a lot of very fast joint movements.

Examples of singular positions

JT4 and JT6 are parallel




JT1 and JT6 are parallel



19.1 LINEAR INTERPOLATION

In this type of interpolation robot moves from the current position to the destination in that way that the TCP moves along straight line in a 3D space.




19.2 JOINT INTERPOLATION

In this type of interpolation robot moves from the current position to the destination in that way that all axes end motion at the same time. This movement creates an unpredictable TCP path in a 3D space. This motion is not effected by singularity points.



19.3 CIRCULAR INTERPOLATION

In this type of motion robot moves from the current position to the destination through the middle point in that way that the TCP creates a 3D circular line in a 3D space.




ASTORINO Operation Manual

20 astorino Software

20.1 Basic information

All data is stored on the internal micro SD card, which is located on a microcontroller board inside the robot base. If the robot is switched off user data is not deleted.

Main window overview.





1. Status Current status of connected robot
2. Application controls Closing or minimizing the astorino application
3. Operations tabs Switching between different operations tabs

ASTORINO Operation Manual

20.2 Visualization Window

To open the visualization window and see the operation of the Astorino robot in real time, click one of these two buttons



20.2.1 Visualization window handling

The visualization window allows you to add 3D objects to the scene with the robot. The program supports stl files and allows you to add basic three-dimensional shapes. You can add each feature as one of three object types:

- Obstacle – objects of this type are static objects of the scene
- Work – objects of this type can be moved by a robot
- Tool – objects of this type always move with the robot flange.


The visualization window menu consists of the following elements::



| | |
|---|---|
|  | Enables or disables the Working Space view |
|  | Enables or disables the 3D model of a standard grippers |
|  | Lists Tool, Obstacle, or Work objects |
|  | Opens the .stl file and loads it as one of the Tool, Obstacle, or work class objects |
|  | Enables the object modification menu, allows you to change the position of the object or change its color |
|  | Deletes the currently selected object in the drop-down list |
|  | Enables the menu of the 3D Simple Shapes Generator |
|  | Enables the generation of robot trajectory visualizations |
|  | Disables and clears the visualization of the robot's trajectory |
|  | Saves robot trajectory visualization points to .traj files |
|  | Enables the visualization window settings menu |


20.2.2 Object types

Work – Work class objects can be moved by a robot. For an object to be captured, the TCP point must be inside the work object and the control signal must be in a high state.




ASTORINO Operation Manual

Obstacle – Obstacle objects are static visualization elements. They allow you to build a visualization scene, are a visual aspect and potential obstacles.



Tool – Tool class objects are objects that are permanently attached to the robot flange. Thanks to these objects, you can create your own tools, which are mounted on the robot flange.




20.2.3 Simple Shape Generator

The generator of simple three-dimensional shapes allows you to generate the following elements:

- Cube,
- Cuboid,
- Cone,
- Cylinder,
- Sphere,
- Pyramid,
- Pipe.

ASTORINO Operation Manual



Object name, when not entered – assigns another free name to the object automatically.

The size of the object, depending on the figure, should be given from 1 to 3 parameters.

The position under which the figure is to be created.

Selecting the class of the object to be created: Tool, Obstacle, Work.

Add an object to a visualization

Choosing an object color



Closing the generator menu

Example

Add to the visualization an obstacle class cylinder with the following parameters:


- 100 mm high,
- Base radius 20mm,
- Green
- Start position (0,300,0 [x,y,z])
- Any name

To add such an object, enter the following data in the generator menu and confirm with the [ADD] button. The object is added.



ASTORINO Operation Manual

20.2.4 Objects modify menu



The name of the currently modified figure.

Sliders and text boxes to change the position of an object on a visualization.

Setting the resolution of the above sliders

Close the modification window.

Apply settings.

The quick color selection area, clicking the mouse button on a specific color will allow you to select it as the color of the object being modified

Preview window selected colors.

Set an object opacity.

Currently selected color, clicking on this area will open the advanced color selection window


Apply settings.

20.2.5 GripBox settings


GripBox is a virtual area in which WORK objects can be gripped by a robot.

WORK object must be in contact with GripBox to be picked up.

ASTORINO Operation Manual




To configure the GriBox click on Grip box menu and then set required settings.



ASTORINO Operation Manual


20.2.6 Visualization settings menu

| | |
|--|--|
|  | <p>Internal signal (from the pool 2001-2016) that enables or disables the generation of trajectory points on the visualization.</p> <p>Time every time another trajectory visualization point is created.</p> <p>Save and restore the position of elements on the visualization.</p> <p>Changing the position of the robot on the visualization.</p> <p>Apply settings.</p> <p>Close the settings menu.</p> <p>Import visualizations from an .xml file.</p> <p>Export visualizations to xml files. The export does not save the opened stl files. Only their names. Copy the files separately.</p> |
|--|--|

ASTORINO Operation Manual


20.2.7 Working Space visualization

Visualization window allows to display all four Working Spaces. Select which one needs to be added to the scene and click on [WS1..4] button. Clicking again will hide the Working Space 3D model.



20.2.8 Working Range visualization

Visualization window allows to display working range of the robot. Click [Range] to add or remove 3D model of working range.



ASTORINO Operation Manual

20.3 Status



When the background of a field is highlighted, it means that:

1. Connected A robot is connected to the astorino software
2. Ext. Control External user connected via communication protocol
3. Error An error has occurred
4. Ready No emergency stop, no errors , the stepper motors are enabled and zeroing is done
5. Motors The stepper motor drivers are active
6. EMERGENCY STOP Emergency stop is pressed and active
7. SAFETY FENCE Safety fence is open
8. Cycle The program sequence is being executed
9. Hold The robot is stopped
10. Home The robot is in its home position
11. RTC External user is connected and Real Time Control is active
12. EXT_IT The robot was stopped by an external interrupt

ASTORINO Operation Manual


20.4 Control



1. Motors Status and control over the motors
2. Control Display of operation mode, stop robot, move to home position, error acknowledgement and zeroing
3. Robot Type Robot firmware version and serial number
4. Connection Select and configure interface, establish connection or disconnect
5. Language Selection of the displayed language


ASTORINO Operation Manual

20.4.1 Motors (ON/OFF)



Pressing [MOTOR ON] activates the stepper motor drivers. This is only possible if no error is present! (Error-box)

The status indicates the motor state (Motors ON).





Pressing MOTOR OFF disables the stepper motor drivers.

ASTORINO Operation Manual

⚠ WARNING

Robot CANNOT be operated until zeroing procedure has been completed!


If the axis zeroing has not been performed, the motors will immediately shut down after the user confirms the warning window. The robot is equipped with brakes on the JT2 and JT3 axes, which prevent the arm from dropping in case of a power loss. However, caution should be exercised during this procedure.



When [Zeroing] is present, the Astorino moves automatically to its safe power off position after the warning message has been acknowledged.


ASTORINO Operation Manual

20.4.2 Control




1. **[REPEAT/TEACH]** – Changes the operation mode. The button turns green when the robot is in automatic mode (REPEAT) and blue when it is in teach mode (TEACH).
2. **[HOLD]** – Stops the robot.
3. **[Reset]** – Reset errors.
4. **[Home]** – Moves the robot to home position (adjustable – see chapter 12.6).
5. **[Zeroing]** – Zeros the axes of the robot (needs to be done after the motors are enabled).

20.4.3 Connection



1. COM port - Displays the different ports to which the robot is assigned. This list is empty if no robot is connected to a PC via USB
2. Connection Type - Select the connection method being used (USB cable / network cable).
3. IP Address - enter the IP address of the robot. This is used only for Ethernet communication.
4. **[CONNECT/DISCONNECT]** – click the button to connect to the robot or to disconnect it.

ASTORINO Operation Manual
20.5 JOG


| | |
|---------------------------|--|
| 1. Jogging | Specify traverse mode and traverse speed, move the robot |
| 2. Current Position | Tool selection, angle display*, current robot position |
| 3. STEP – TEACH | Set step size and step speed |
| 4. JT7 – JOG | Move linear axis (JT7) - if attached |
| 5. Execute Motion Command | Execute the specified command |
| 6. Teach Point | Specify a point to teach or to move to |
| 7. Control | Duplicated functionality from Control Tab |

ASTORINO Operation Manual



1. Motor on/off
2. Home
3. Hold
4. Reset
5. Zeroing
6. Switch Teach/Repeat
7. CLAMP control – Close and Open the gripper
8. Open Visualization window
9. Status of Dead-Man switch


* Angle display or applied rotation sequences

When calculating motion, the robot uses classic EULER (OAT) to calculate the robot path and position.

For ease of teaching **Roll-Pitch-Yaw** is used as its more intuitive for the user this is automatically converted to a OAT position by the robot.

Classic Euler O,A,T Angles

The position format (POSE) used by Kawasaki robots consists of a position XYZ in millimeters and an orientation OAT, which is specified by three angles in degrees, where **O** is rotated around the **Z-axis**, **A** rotates around the rotated **Y-axis** (**Y'**) and **T** rotates around the rotated **z-axis**.




Roll-Pitch-Yaw (RPY):

Roll-pitch-yaw angles are special Euler angles (position angles) that are used to describe the orientation of an object in 3-dimensional space.

roll axis (longitudinal) **X**


pitch (cross axis) **Y**

yaw (vertical axis) **Z**




ASTORINO Operation Manual

20.5.1 Jogging



Choose reference system:

- BASE (base coordinates)
- TOOL (tool coordinates)
- JOINT (single axis mode)
- CONV (synchronous in combination with an optional external encoder - conveyor)
- WORK (Work coordinates)




Setting the movement speed of the robot in steps.

| Speed | Cartesian mode | Single axis mode (JOINT) |
|-------|----------------------|--------------------------|
| 1 | Movement by distance | Rotation by fixed angle |
| 2 | 5 mm/s | 2°/s |
| 3 | 10 mm/s | 4°/s |
| 4 | 30 mm/s | 8°/s |
| 5 | 60 mm/s | 12°/s |

ASTORINO Operation Manual


The "▲+" and "▼-" keys move the robot in teach mode at the selected speed:



- BASE (Cartesian coordinates): X, Y, Z, RX, RY, RZ
- TOOL (Cartesian coordinates): x, y, z, rx, ry, rz
- JOINT (Single axis): JT1, JT2, JT3, JT4, JT5, JT6
- CONV (Cartesian coordinates): X, Y, Z, RX, RY, RZ
- WORK (Cartesian coordinates): X, Y, Z, RX, RY, RZ

If currently selected speed is 1 (step) then after pressing JOG (+/-) buttons robot executes step motion. Step motion is set in STEP-TEACH section.

In addition, the robot can be moved using a keyboard:



ASTORINO Operation Manual

20.5.2 Current Position

Current Position

| | | | | |
|--|---|---|---|--|
| Tool: <input type="button" value="1"/> | Work: <input type="button" value="1"/> |  |  | |
| <input checked="" type="radio"/> OAT | <input type="radio"/> RPY | X [mm] <input type="text" value="0.000"/> | Y [mm] <input type="text" value="-3.500"/> | Z [mm] <input type="text" value="717.110"/> |
| O [°] <input type="text" value="180.000"/> | A [°] <input type="text" value="0.000"/> | T [°] <input type="text" value="180.000"/> | | |
| JT ₁ [°] <input type="text" value="0.000"/> | JT ₂ [°] <input type="text" value="0.000"/> | JT ₃ [°] <input type="text" value="0.000"/> | | |
| JT ₄ [°] <input type="text" value="0.000"/> | JT ₅ [°] <input type="text" value="0.000"/> | JT ₆ [°] <input type="text" value="0.000"/> | | |
| JT ₇ [mm/°] <input type="text" value="0.000"/> | Conveyor 1 <input type="text" value="0.500"/> | Conveyor 2 <input type="text" value="0.500"/> | | |

Tool selection (1-4)

Show visualization

Display for DryRun mode (visible only if DryRun is active)

Work selection (1-2)

Specify the display of OAT or RPY angles

Current arm-position

20.5.3 STEP - TEACH

STEP - TEACH

| | |
|---|---|
| STEP DISTANCE: <input type="text" value="10"/> |  |
| STEP SPEED: 3deg/s | |

STEP DISTANCE


Value in mm/° for the movement

STEP SPEED

Speed in % or mm/s

ASTORINO Operation Manual

20.5.4 Teach Point




Select a point from the list to be taught.

Select whether the point is to be approached linearly (TRANS) or by the fastest route (JOINT).


Pressing the [Teach] button saves the point in the robot's memory.

20.5.5 Execute Motion Command




Command (possible movement commands):

- LMOVE (linear)
- JMOVE (fast)
- JUMP (special*)
- LAPPRO
- JAPPRO



once [Execute] is pressed the specified movement command is executed for the point selected in the Teach Point area.




Special command* JUMP:

The robot moves with a distance "a" to be defined from one point (e.g. P1) to the next (e.g. P2). The distance "a" is the Z-direction in tool coordinates (TOOL).

ASTORINO Operation Manual

20.6 Points



All points stored in the robot are displayed in tabular form.

Either all TRANS or JOINT points can be displayed. Points from 0 to 99 are labeled Px for example P0 or P10, points from 100 to 255 are user points and have name as user specify.

In the drop-down list (1), you can select in which direction the point data is to be loaded or saved. You can select either the connected computer or the robot controller.


The [LOAD] button loads data from the robot memory or from *.loc files into the ASTORINO robot controller.

With the [SAVE] button, the data in the robot memory or in a *.loc file on the in a *.loc file on the PC.


The [DELETE] button removes the selected item from the astorino software and from the robot memory at the same time.

ASTORINO Operation Manual

20.7 Home/Tool



20.7.1 Home




The [Set Home] button saves the current position of the robot as the home position.

Selecting Manual allows manual entry of data for the HOME position. Pressing [Set Home] button saves the Home position data to the robot's memory.

Pressing the [Home] button on the Control tab causes the robot to return to the saved position in the future!

ASTORINO Operation Manual

20.7.2 Tool




Various tools such as grippers, tips or other can be called up and parameterized via the tool drop-down menu.

Enter the associated tool data manually.

Either this data is already known and documented from the design, or must be determined and entered manually.

Clicking on the [Upload Tool] button saves the entered data to the robots memory.

20.7.3 TOOL WIZARD




This section allows a user to calculate a new TCP (Tool Center Point) using a 4 points or 6 points method.

The 4 points method calculates x,y,z values of the Tool.

The 6 points method allows to calculate x,y,z and Rx,Ry,Rz values of the Tool. Refer to the TOOL calculation section in this manual.

ASTORINO Operation Manual

20.7.4 WORK




This section allows an user to check and change WORK OAT values.

Either this data is already known and documented from the design, or must be determined and entered manually.

Clicking on the [Upload Work] button saves the entered data to the robots memory.

ASTORINO Operation Manual


20.7.5 WORK WIZARD



This section allows a user to calculate a new WORK coordinate system using a 3 points method.

Teach all 3 points on reference plane and then click [Calculate Work]

20.7.6 Power off position




This area contains information about the safe power off position.

- The [Save] button saves a manually entered position.
- The [Current] button saves the current robot position as the power off position.
- [Default] resets the values to factory settings.

 ASTORINO Operation Manual

20.7.7 Zeroing order



| JT1 | JT2 | JT3 | JT4 | JT5 | JT6 | JT7 |
|---|---|---|---|---|---|---|
| 2 | 3 | 4 | 5 | 6 | 7 | 1 |
| <input checked="" type="checkbox"/> go to 0 |

This area shows information about the zeroing order of axes. The user can set the sequence of zeroing for all axes. Specify [1..7] for the order the axes for all axes (multiple axis can be zeroed in the same step) and select if the axes should or should not go to 0 (zero) position after location is found.

- The [Default] button sets zeroing order to default order.
- The [Manual] button activates the manual settings section.
- The [Save] button is used to save a manually entered position.


ASTORINO Operation Manual

20.8 Moving Area

On the [Moving Area] tab the allowed working area of the Astorino robot can be defined.

To modify the allowed workspace, a higher level of access must be entered. To do this, type the command in the Robot Terminal „z_user 3“

20.8.1 XYZ Limits



With the help of two points **P1** and **P2**, a virtual rectangular volume is created that defines the area in which the robot is allowed to move.


P1 – shows the minimal values

P2 – shows the maximal values

- [Get Current] the current position of the robot is captured and stored in the selected row of the position table.
- The zone can be defined manually by entering values.
- [Default] button resets the values to factory settings.
- [SAVE] the data to the robot memory.

ASTORINO Operation Manual

20.8.2 Range




On this tab user can set the motion limits of all joints separately. Type in max and min angle value of each joint and then press [SAVE] to upload changes to the robot. Pressing [Default] will restore factory settings of joints range.

ASTORINO Operation Manual

20.8.3 Working Space


Working Space is virtual area which can be used to inform other devices of the position of the robot arm. Working Space uses dedicated signals to work.



On this tab user can set the Working Space areas. Type in Upper End and Lower End values of each Working Space and then press [SAVE] to upload changes to the robot. You can set up to four different Working Space.



ASTORINO Operation Manual

20.9 Programs



In this tab the robot can be programmed in a simplified version of the Kawasaki AS language.

ASTORINO Operation Manual




next step in TEACH / REPEAT mode or act as GO button – executes currently selected program step,

25. Traverse speed - Set and change in TEACH mode

ASTORINO Operation Manual

- * When the Astorino is switched on, the program defined as the startup program is loaded into the robot controller's working memory and is directly ready to be executed.



Sample program named *hello*

If the program is executed, the robot moves to point P1 in a straight line (Linear MOVE).

When the point is reached, the robot moves on a direct path to P2. The variable x is now assigned the value 0.


The **IF** loop queries if x has the value 0.

If this is the case, the **HOME** command is executed and the robot moves to home position.

For more information about AS Langage please refere to "astorino – AS language manual"

ASTORINO Operation Manual


20.10 System Setting



| | |
|----------------------------------|---|
| 1. I/O | In this window shows the status of the signal INPUTS and switch the OUTPUTS ON/OFF by clicking the corresponding buttons |
| 2. Back-up and file up-load | Enables to perform a backup of robots data, restore robot settings from a file or upload AS File. This section also allows to initialize robot to factory settings. |
| 3. Terminal | Input and display of data. |
| 4. IO, Dedicated IO, Conveyor... | Status of inputs and outputs (I/O), Configure I/O, other settings. |
| 5. INTERNAL | Display and switch internal signals. |

ASTORINO Operation Manual

20.11 I/O



In this window shows the status of the signal INPUTS and switch the OUTPUTS **ON/OFF** by clicking the corresponding buttons.

INPUTS 57,58 and OUTPUTS 57,58 are reserved for B version of the robot and are located on the JT3 arm

INTERNAL – here you check or force the status of the internal signals. (**ON** , **OFF**)

20.12 Terminal



The terminal is used to display information from the robot and also give the robot commands.

All move commands like LMOVE, HOME etc. Must be preceded by "DO" and the robot must be READY and in REPEAT mode. For example "DO LMOVE P1".

The terminal can be used to read variable values (for example "PRINT x"), teach point(for example HERE P1), set variables (for example x = 10) and so on.

Here is a list of Terminal only commands:


| | |
|--------------|---------------------------------------|
| CPUTEMP | Prints CPU temperature |
| FREE | Prints available RAM memory in % |
| ERESET | Resets error |
| ZPOWER ON | Turns MOTORS ON |
| ZPOWER OFF | Turns MOTORS OFF |
| HOLD | Pauses the currently running program |
| CONTINUE/RUN | Continues the paused program |
| ZZERO x | Starts zeroing of a specific axis - x |
| HALT | Pauses the currently running program |

ASTORINO Operation Manual

| | |
|-----------------|--|
| EXECUTE x | Starts currently selected program, if name specified runs chosen program (x) |
| PRIME x | Selects chosen program by name |
| STOP | Stops currently running program (Cycle) |
| REP_ONCE ON/OFF | Turn on or off Repeat Once |
| STP_ONCE ON/OFF | Turn on or off Step Once |
| STPNEXT | Triggers next step in step once mode program execution |
| ZIOACTIVE x | Turns ON(x:1)/OFF(x:0) IO module |
| CONTINUE NEXT | Runs next step |

20.12.1 Status und configuration section

20.12.1.1 Clamp/JT7



Resolution settings example:

- Stepper motor resolution – 200 imps/rev (1.8°) – **[M]**
- Micro stepping settings – 32 – **[uS]**
- Gear ratio – 5:1 – **[i]**
- Spur gear: Module 1, 20 teeth – **[m]**, **[T]**

In this window the handling clamp signals can be set. Handling clamp signals are set to work with **OPENI** and **CLOSEI** commands.


This section also allows to change JT7 settings. User can change the range, speed and resolution of the connected linear track.

Shown here values are default settings for astorino Linear track option.

$$Res = \frac{\pi * T * m}{uS * M * i}$$


ASTORINO Operation Manual

20.12.1.2 MODBUS I/O



In this window shows the status of the Fieldbus Inputs and switch the Fieldbus Outputs **ON/OFF** by clicking the corresponding check buttons. If the INPUT or OUTPUT is ON, the button lights up in yellow colour.

20.12.1.3 Clamp




In this window clamp setting can be changed.

Clamp settings affect OPENI and CLOSEI commands.

ASTORINO Operation Manual

20.12.1.4 Dedicated IO



View and configurate dedicated robot signals. The signals have a fixed prescribed function or statement.

Dedicated Inputs are special input signals like "Reset" or "Cycle Stop".

Dedicated Outputs are special output signals like "Motor ON" and "Error".

Dedicated signals update their state automatically.

Dedicated Inputs:

| Function | Description |
|-------------------|---|
| Motor ON | When selected signal is ON astorino will turn on the motors |
| Cycle Start | When selected signal is ON astorino will start currently selected program |
| Reset | When selected signal is ON reset function is executed |
| EXT_IT(Hold) | When selected signal is ON astorino operations are held |
| Interrupt motion | When selected signal is ON astorino will interrupt current motion instruction and skip to next program line |
| Motor OFF | When selected signal is ON astorino will turn off the motors |
| Zeroing | When selected signal is ON astorino will start zeroing procedure |
| Cycle Stop | When selected signal is ON astorino will stop program execution |
| MZH | MZH (MOTOR ON -> ZEROING -> HOME) – this is a special sequence on the astorino designed to HOME the robot with one bit from the POWER ON state. |
| Prime Start-up PG | When this signal is ON Start-up program is loaded to RAM memory and can be started. |


Dedicated Outputs:

| Function | Description |
|----------|---|
| Cycle | When cycle is ON selected signal is ON |
| Repeat | When current mode is REPEAT selected signal is ON |
| Teach | When current mode is TEACH selected signal is ON |
| Motor ON | When motors are ON selected signal is ON |
| ESTOP | When ESTOP is ON selected signal is ON |
| Ready | When Ready status is ON selected signal is ON |
| Error | When Error status is ON selected signal is ON |
| Hold | When HOLD is ON selected signal is ON |

ASTORINO Operation Manual

| | |
|--------|---|
| Zeroed | When zeroing is done selected signal is ON |
| WS1..4 | When current position of robot is inside Working Space then selected signal is ON |

20.12.1.5 Collision detection (B version of the robot)



Robot is equipped with an accelerometer for collision detection.

Here the thresholds for collision detection can be changed.*


The [4G Mode] checkbox allows the high level thresholds to be turned on/off. Impact sensing is set to maximum of 4G (Earth gravity).

The [SAVE] button saves thresholds to the robot's memory.

The [Calibration ON/OFF] button starts or stops the auto calibration of the thresholds.

*to change data 3 user level is necessary (type command "Z_USER 3" in the terminal)

20.12.1.6 Conveyor




Here you can set the direction of movement of the conveyor belt. We set the direction according to one axis of the BASE system of the robot, as well as the resolution of mm / bit

You can also attach a virtual encoder. This allows you to simulate applications that use tape tracking. Select from the list which conveyor you want to start (CONV1 or CONV2), attach the checkbox (Enable Virtual Encoder), and then use the [Start] or [Stop] buttons to turn the virtual encoder on or off.

The values of the virtual and physical encoder are displayed from the JOG tab

ASTORINO Operation Manual

20.12.1.7 Ethernet



In this area you the settings for Ethernet communication is changed.


The operation of the Ethernet port can be set to:

- Connection to the astorino software
- Modbus TCP Server
- TCP/IP or UDP
- Modbus TCP Client

The [Save] button saves the changes to the memory of the robot.

After saving, a restart of the robot is required.


20.12.1.8 Calibration



This section allows user to calibrate the robot and check the magnetic sensors on the axis. If the buttons with a name H_x , where x is $1..7$ are Yellow then the zeroing sensor is active (ON).

ASTORINO Operation Manual

20.12.1.9 Firmware




In this subtab the Astorino firmware can be updated.

20.12.1.10 Modbus Set.

This section allows to configure Modbus TCP communication settings.

When Ethernet port is set as MODBUS TCP Server



In this window user can set number of registers (max 3), register number from 1 to 9999 and on which I/O channel which register should operate.

ASTORINO Operation Manual

When Ethernet port is set as MODBUS TCP Client

| Dev. 1 ✕ | | Dev. 2 ✕ | | + | | | | | | | | |
|---|---------|----------|--|---|----------|---------|-------|------|-------|-------|-------|-------|
| IP Adress 192 . 168 . 0 . 100 | | | | | | | | | | | | |
| INPUT 3 | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Register</th> <th>Channel</th> </tr> </thead> <tbody> <tr> <td>30001</td> <td>9-24</td> </tr> <tr> <td>30002</td> <td>25-40</td> </tr> <tr> <td>30003</td> <td>41-56</td> </tr> </tbody> </table> | | | | | Register | Channel | 30001 | 9-24 | 30002 | 25-40 | 30003 | 41-56 |
| Register | Channel | | | | | | | | | | | |
| 30001 | 9-24 | | | | | | | | | | | |
| 30002 | 25-40 | | | | | | | | | | | |
| 30003 | 41-56 | | | | | | | | | | | |
| OUTPUT 3 | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Register</th> <th>Channel</th> </tr> </thead> <tbody> <tr> <td>40001</td> <td>9-24</td> </tr> <tr> <td>40002</td> <td>25-40</td> </tr> <tr> <td>40003</td> <td>41-56</td> </tr> </tbody> </table> | | | | | Register | Channel | 40001 | 9-24 | 40002 | 25-40 | 40003 | 41-56 |
| Register | Channel | | | | | | | | | | | |
| 40001 | 9-24 | | | | | | | | | | | |
| 40002 | 25-40 | | | | | | | | | | | |
| 40003 | 41-56 | | | | | | | | | | | |
| Connected <input type="checkbox"/> | | | | | | | | | | | | |
| Save | | | | | | | | | | | | |

In this window user can set the device settings to which robots is connecting. IP address, Number of registers (max 3), register number from 1 to 9999 and on which I/O channel which register should operate.

Also maximum of 3 devices can be connected at the same time.

Only 3 registers can be set for all devices,


For example

| Dev. 1 ✕ | | Dev. 2 ✕ | | + | | | | | | |
|--|---------|----------|--|---|----------|---------|-------|------|-------|-------|
| IP Adress 192 . 168 . 0 . 100 | | | | | | | | | | |
| INPUT 2 | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Register</th> <th>Channel</th> </tr> </thead> <tbody> <tr> <td>30001</td> <td>9-24</td> </tr> <tr> <td>30002</td> <td>25-40</td> </tr> </tbody> </table> | | | | | Register | Channel | 30001 | 9-24 | 30002 | 25-40 |
| Register | Channel | | | | | | | | | |
| 30001 | 9-24 | | | | | | | | | |
| 30002 | 25-40 | | | | | | | | | |
| OUTPUT 2 | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Register</th> <th>Channel</th> </tr> </thead> <tbody> <tr> <td>40001</td> <td>9-24</td> </tr> <tr> <td>40002</td> <td>25-40</td> </tr> </tbody> </table> | | | | | Register | Channel | 40001 | 9-24 | 40002 | 25-40 |
| Register | Channel | | | | | | | | | |
| 40001 | 9-24 | | | | | | | | | |
| 40002 | 25-40 | | | | | | | | | |
| Connected <input type="checkbox"/> | | | | | | | | | | |
| Save | | | | | | | | | | |

| Dev. 1 ✕ | | Dev. 2 ✕ | | + | | | | |
|--|---------|----------|--|---|----------|---------|-------|-------|
| IP Adress 192 . 168 . 0 . 101 | | | | | | | | |
| INPUT 1 | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Register</th> <th>Channel</th> </tr> </thead> <tbody> <tr> <td>30001</td> <td>41-56</td> </tr> </tbody> </table> | | | | | Register | Channel | 30001 | 41-56 |
| Register | Channel | | | | | | | |
| 30001 | 41-56 | | | | | | | |
| OUTPUT 1 | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Register</th> <th>Channel</th> </tr> </thead> <tbody> <tr> <td>40001</td> <td>41-56</td> </tr> </tbody> </table> | | | | | Register | Channel | 40001 | 41-56 |
| Register | Channel | | | | | | | |
| 40001 | 41-56 | | | | | | | |
| Connected <input type="checkbox"/> | | | | | | | | |
| Save | | | | | | | | |

ASTORINO Operation Manual

20.13 About




This tab shows the current version of the astorino software and the compatible firmware version to the current astorino software.

ASTORINO Operation Manual

20.14 Firmware Update

20.14.1 Basic information


Astorino software after startup will automatically check if there is a new version available and if so, informs user.



Clicking [OK] button will download the new version to user specified location on the hard drive.

Then user needs to uninstall the old version from a PC and install a new one.

After connecting to the robot astorino software will check if the firmware on the robot is up to date. If the new firmware is available, application will inform user about it.



Clicking [OK] button will download the new to user specified location on the hard drive.

The latest firmware version can also be downloaded from KAWASAKI ROBOTICS FTP server: <https://ftp.kawasakirobot.de/Software/Astorino/>

or contact technical support:
Tech-Support@kawasakirobot.de

ASTORINO Operation Manual


20.14.2 Update procedure

To update the firmware, start the astorino software. Connect the robot to the PC via USB cable.

[ATTENTION]


Make sure that the software is **not** connected to the robot. The motors must be switched off! Connect button was not pressed.

Interrupting the process might damage the CPU, please do not turn off the robot during update procedure!



Navigate to the **[System Setting]** Tab and to the IO configuration area.

Click on the right arrow symbol until the **[Firmware]** subtab is visible.




Press **[Update Firmware]** to open the file selection window.


Select the *.hex file which contains the new firmware.

ASTORINO Operation Manual


File selection window:



Confirm the upload to start loading the new firmware to the robot's memory:




The firmware update is being performed.



ASTORINO Operation Manual


After the firmware is installed observe the red (Error) led on the robots base.

If the red led starts to flash slowly (around 2 times per second).




Turn off the robot and turn it on again. This is an error from the SD card inside robots base, CPU was not able to restart the card after firmware update. Resetting the power solves the problem.

If the red led starts to flash (around 5 times per second).




This means that the robot needs to update the data on the SD card. The procedure will perform automatically. When the procedure is complete, the red LED will turn off. And when connected to the computer, there will be a message that the SD card data repair/update procedure is complete



20.15 Update fail recovery

If the update process is interrupted then the CPU might not work and Windows will not detect the robot. Reset the CPU to the factory settings by pressing the white reset button on the CPU board for 13s to 17s.



The white button is located on the CPU-board inside the robot base. To access it unscrew and remove the rear-top cover.



Do not use any metal objects inside the robot base during CPU factory reset.

Red led on the CPU unit will start to blink. Once the hard reset is finished the orange led on the CPU board will blink slowly and the red (Error) led on the robot base will blink slowly.

20.16 AS-language

The astorino can be programmed using a basic version of the Kawasaki AS language, which is used on all Kawasaki Robotics industrial robots.

Current list of supported commands and functions:

(x,y,z represent values - e.g. SPEED 100 ALWAYS
 p for points or point names - e.g. JMOVE P10)

| Name | Description |
|----------------|--|
| ACCEL x | Robot acceleration in % for next motion command |
| ACCEL x ALWAYS | Robot acceleration in % |
| ALIGN | Align TOOL z-axis to closest BASE axis |
| C1MOVE p | Determines the intermediate point of circular interpolation |
| C2MOVE p | Moves the robot to point p in circular interpolation by passing through the point specified in the C1MOVE p command; the C1MOVE command must be used before the C2MOVE command |
| CVCOOPJT x | Sets cooperation between conveyor number 1 or 2 |
| CVDELAY x | The robot maintains the current conveyor position for the time x |
| CVLAPPRO p,x | Moves in the -Z direction of the tool for a given distance x from point p linearly with conveyor tracking |
| CVLDEPART x | Moves the robot from current position at a specified distance x from the current position along the -Z axis of the tool with conveyor tracking |
| CVLMOVE p | Linear motion to the point p with conveyor tracking |
| CVRESET x | Resets external encoder counter to x value |
| CVWAIT x | Waits until external encoder counter gets to x value |
| DECEL x | Robot deceleration in % for next motion command |

ASTORINO Operation Manual

| | |
|-----------------|--|
| DECCEL x ALWAYS | Robot deceleration in % |
| DISTANCE(p,p) | Calculates distance between two points |
| DLYSIG x,y | Activates signal x (1–8 or int. 2001–2016) after y time passed in seconds |
| DRIVE x,y,z | Move single axes, by x- axis, y – degree, z - speed |
| DRAW x,y,z | Linear motion with respect to x,y,z according to BASE |
| \$DECODE(x,y) | The function searches the string x for the separator y and extracts all characters that are before the separator. These characters are output again as a string and at the same time removed from the original string! |
| \$ENCODE(x) | Changes number to a string |
| ERESTET | Reset error |
| EXISTCOM | Status of HOST communication data ready |
| HERE p | Save the current position of the robot to point x |
| HOME | Moves the robot to HOME position |
| INRANGE(p) | Checks if point is in range of a robot arm |
| JAPPRO p,x | Moves in the Z direction of the tool a certain distance x from the joint p |
| JUMP p,x | Special command: JUMP to position p, where x is a joint or a Cartesian point, x corresponds to the stroke height. |
| JMOVE p | Motion of the robot along the p (joint) position, where p is a joint or Cartesian point |
| LMOVE p | Linear motion to the point p |
| LAPPRO p,x | Moves in the Z direction of the tool for a given distance x from point p linearly |
| LDEPART x | Moves the robot from current position at a specified distance x from the current pos. along the Z axis of the tool |
| POINT p | Creates variable x of the point |
| PRINT x | Print data/text on the Terminal |

ASTORINO Operation Manual

| | |
|---------------------|--|
| PULSE x,y | Activates signal x (1-8 or int. 2001-2016) for y time (sec.) |
| SEND x | Send data to HOST (Serial communication) |
| SHIFT(p BY x,y,z) | Creates a new point based on the displacement of p Example: POINT TST = SHIFT(P1 BY 10,0,0) |
| SIG(x) | Checks the state of the x signal — returns TRUE or FALSE Example: IF SIG(2001) == TRUE THEN |
| SIGNAL x | Activates signal x (1-8 or int. 2001-2016) |
| SIGNAL -x | Deactivates signal x (1-8 or int. 2001-2016) |
| SPEED x | Robot speed in % for next motion command |
| SPEED x ALWAYS | Robot speed in % |
| SPEED x MM/S | Robot speed in mm/s (max. 250 mm/s) for next motion command |
| SPEED x MM/S ALWAYS | Robot speed in mm/s (max. 250 mm/s) |
| SWAIT x | Pauses the program until the high state of the x signal (1-8 or 2001-2016) |
| SWAIT -x | Pauses the program until the state of low signal x (1-8 or 2001-2016) |
| TDRAW x,y,z | Linear motion with respect to x,y,z according to TOOL |
| TOOL p | Selecting tool data from point transformations |
| TOOL x | Selecting one of the TOOL systems (x = 1,2,3) |
| TWAIT x | Pauses the program for x seconds |
| TYPE x | Print data/text on the Terminal |
| X= CVPOS | Read conveyor data 1 |
| X= CVPOS2 | Read conveyor data 2 |
| X = RECEIVE | Read HOST data from buffer |
| Y = VAL(x) | Changes string value to a number |

ASTORINO Operation Manual

- Conditional expressions:
 - IF ... THEN ... ELSE ... END
 - IF ... THEN ... END
 - CASE ... OF ... VALUE ... ANY... END
- Loops:
 - FOR ... TO ... END
 - DO ... UNTIL
 - WHILE ... END
- Mathematical expressions and functions:
 - +, -, *, /, ^, MOD
 - SIN, COS, ATAN, ABS


ASTORINO Operation Manual

20.17 Programming


20.17.1 Creating a new program

The **Program** area is located in the **Programs** tab.


The icon located on the far left creates a new program:



A window will appear to enter a name for the program.



A new program template is generated:




The **[Upload]** button starts flashing yellow. This is a sign that the program is modified on the PC but not uploaded to a robot.

ASTORINO Operation Manual

20.17.2 Write a program


Program



```
1 .PROGRAM test2
2   SPEED 60
3   SPEED 100 MM/s
4   i = 0
5   n = 5
6   FOR i = 0 TO n
7     POINT tst = SHIFT(P1 BY 10*i,0,0)
8     LAPPRO tst, 50
9     LMOVE tst
10    TWAIT 1
11  END
12 .END
13 |
```

20.17.3 Loading a program onto the robot

To upload the program to the robot's memory press the **[Upload]** button:



```
1 .PROGRAM test2
2   SPEED 60
3   SPEED 100 MM/s
4   i = 0
5   n = 5
6   FOR i = 0 TO n
7     POINT tst = SHIFT(P1 BY 10*i,0,0)
8     LAPPRO tst, 50
9     LMOVE tst
10    TWAIT 1
```


ASTORINO Operation Manual

20.17.4 Running currently selected line

To run a currently selected line press and hold Next Step/GO button and at the same time press and hold left CTRL key on a keyboard. Robot must be in Teach Mode.



Releasing CTRL or GO button will decelerate the robot.




⚠ WARNING

Running code by GO button will execute only no program flow control commands. Commands like IF, FOR, WHILE etc. will return error.

ASTORINO Operation Manual

20.17.5 Running a program



Click on the Play icon in the Program Control bar ► [Cycle Start] to run the program from the currently selected line:



20.17.6 Stopping a program


To stop the execution of the program, you must first pause the robot by pressing the [HOLD]



And then after pausing the robot, click the Play icon on the [Cycle Start]

ASTORINO Operation Manual

program control bar ► to stop the program:




21 Example programs

21.1 Pick & Place – Palletization example

This program picks cubes from single tower and places them into specifiable numbers of: Rows, Columns and Layers.

The user can adjust:

- The size of the workpiece (cubes)
- Distance between the cubes
- The number of rows, columns and layers



ASTORINO Operation Manual

```

.PROGRAM PAL1
;----- Init -----
deltaX = 60 ;distance between workpieces X
deltaY = 60 ;distance between workpieces Y
deltaZ = 30 ;layer height
numLev = 2
numRow = 1
numCol = 2
numPcs = numLev*numCol*numRow ;pieces count
height = 25 ;height of a workpiece (25 mm)
;----- variable init -----
x = 0
y = 0
z = 1
SIGNAL -1
speed 100 mm/s always
POINT place = p2
POINT pick = P1
POINT pick = SHIFT(p1 BY 0,0,numPcs*height)
;P1 on the table, pick shifted by number of pieces in Z
HOME
LAPPRO pick, 40
;----- Pal-----
FOR z = 0 TO (numLev-1)
  FOR y = 0 TO (numRow-1) ; rows in Y
    FOR x = 0 TO (numCol-1) ;col in X
      POINT pick = SHIFT(pick BY 0,0,-height);calc new pick pose
      JAPPRO pick,40
      speed 20 mm/s
      LMOVE pick
      TWAIT 0.5
      SIGNAL 1 ;close the gripper
      TWAIT 0.5
      LDEPART 50
      LMOVE P3
      POINT place = p2
      POINT place = SHIFT(p2 BY deltax*x,deltay*y,deltaz*z)
      LAPPRO place,30
      speed 20 mm/s
      LMOVE place
      TWAIT 0.5
      SIGNAL -1 ;open the gripper
      TWAIT 0.5
      LDEPART 30
      LMOVE P3
    END
  END
END
.END

```

ASTORINO Operation Manual

21.2 I/O example program

This example program shows how to use signals in multiple ways.


```

.PROGRAM IO
; ----- IO example program
; ----- Robot reads and sets IOs
sensor = 1002 ;sets variable
SWAIT 2001 ;wait until internal 1 signal is on
SIGNAL 8 ;sets 8 output HIGH
IF SIG(sensor) == TRUE THEN
  ;checks if sensor(2 input) is high
  SIGNAL 2002 ; sets 2 internal HIGH
ELSE
  IF SIG(1001) == FALSE THEN
    SIGNAL -8 ;sets 1 output LOW
  END
END
BITS 1,4 = 12
;changes 12 to 4bit binary and sets that on out    puts from 1
data = BITS(1004,4) ;read binary data from inputs
;4 bit from    4th output and changes that to decimal
PRINT data
.END

```

21.3 Serial communication example program

This example shows how to use serial communication. Programs can exchange data between the astorino robot and PC (for example Matlab or Serial Terminal) or microcontroller (for example an Arduino).




M8 connector (Pins: 1 – 5V, 2 - GND, 3 – TX, 4 – RX)

[NOTE]

The parameters of serial communication are:

- Baudrate: 115200
- Date size: 8
- Parity: None
- Handshake: OFF



ASTORINO Operation Manual

```

.PROGRAM SERIAL
; ----- Serial communication example program
; ----- Robot command frame form Serial Port
; ----- frames: P/ or L/x/y/z/
; ----- From X,Y,Z point is created
; ----- Sends current location if frame is P/
SPEED 150 MM/S ALWAYS
$S_FRAME = "XYZ"
$S_FRAME2 = "JT"
WHILE EXISTCOM == FALSE DO
  TWAIT 0.1
END
$TEMP = RECEIVE
$COMMAND = $DECODE ($TEMP, "/")
PRINT $COMMAND
;RECEIVE DATA FROM SERIAL AND CREATE A POINT
IF $COMMAND == "L" THEN
  $VAL1 = $DECODE ($TEMP, "/")
  $VAL2 = $DECODE ($TEMP, "/")
  $VAL3 = $DECODE ($TEMP, "/")
  DATAX = VAL ($VAL1)
  DATAY = VAL ($VAL2)
  DATAZ = VAL ($VAL3)
  POINT TEST = TRANS (DATAX, DATAY, DATAZ, 0, 0, 0)
  POINT/OAT TEST = P0
  LMOVE TEST
  SEND "OK"
END
;SEND CURRENT LOCATION TO SERIAL PORT
IF $COMMAND == "P" THEN
  HERE TEMP
  HERE #TEMP
  DECOMPOSE TAB[0] = TEMP
  DECOMPOSE TAB2[0] = #TEMP
  FOR I = 0 TO 5
    TAB2[I] = TAB2[I]*180/PI
    $S_FRAME = $S_FRAME + $ENCODE (TAB[I]) + "/"
    $S_FRAME2 = $S_FRAME2 + $ENCODE (TAB2[I]) + "/"
  END
  SEND $S_FRAME
  SEND $S_FRAME2
END
.END

```

⚠ WARNING

Serial communication is working with 3.3V, use electronics compatible with 3.3V or use level shifters.

Voltage level of 5V will damage the CPU unit!


22 Tool Data

22.1 Tool data from known dimensions

Enter the dimensions of the tool (TOOL DATA) in the base coordinate system (BASE) of the robot.

Obtain the tool dimensions from existing CAD data or physically measure them .

The following is an example of how to obtain tool data for an arc welding torch.



The burner is angled at 22 degree.

The length of the torch from the flange surface (axis 6) to the tip of the nozzle is 127.45mm in Z-direction.

The angled torch results in an offset in the Y-direction of 13.11mm.

The measurements for the TCP are always from the center of the robots flange.

ASTORINO Operation Manual

This tool example has the following TCP coordinates.

| | | |
|-----------|------------|--------------------------------------|
| X[mm] | 0.0 | |
| Y[mm] | 13.11 | |
| Z[mm] | 127.45 | |
| Rx: -22,0 | [O: 90.0] | Rx is the rotation around the X axis |
| Ry: 0.0 | [A: 22.0] | Ry is the rotation around the Y axis |
| Rz: 0,0 | [T: -90.0] | Rz is the rotation around the Z axis |

22.2 Automatic Tool (Coordinates Data) Registration

This chapter describes operation procedures for automatic registration of tool coordinates values.

[ATTENTION]

Automatic tool registration is a kind of teaching. Its usage is limited to personnel who have completed special training and are qualified for teaching or supervising robot operations.

22.2.1 Overview of Automatic Tool Registration Function

A variety of different shaped tools (gripper, hand, etc.) can be mounted on the robot flange. If the tool data is not measured correctly, the robot motion trajectory will deviate from the taught path.

The tool data is essential for operating the robot correctly. In general, the tool data should be input by numeric values and registered, but in some cases measurement of the position and orientation of the tool coordinates may not be accurate, or take a long time.


This function makes it possible to automatically calculate the tool transformation values by teaching several points in space without having to enter values. For this procedure a measuring jig with sharp point is required, for example a big screw and the cone tool attachment (not delivered with a robot).



ASTORINO Operation Manual

22.2.2 Required Data for Automatic Tool Coordinates Registration

When using the automatic tool registration function, the set of pose data is stored (A1,A2,A3,A4,B,C). The pose data measurement is taken by aiming at one teaching point from 4 or 6 different tool poses, as described below.




Teaching pose consists of six base poses, A1, A2, A3, A4, B and C.


22.2.3 Teaching the Four Base Poses

The four position method of TCP calculation determines the offsets of the TOOL data in X,Y,Z dimensions.

Teach the 4 Poses (A1, A2, A3, A4) at the same position data but with different approaches, ensure the Tool tip is at the same point on the measuring jig. Ensure that the angles between each orientation are as large as possible within the preferred range 45° - 90°. If the range is lower than 45° the accuracy of the calculation might be less precise. The wrist flange face should have a different plane for each base orientation. Teach each base pose so that the tool coordinates and measuring jig origins are in contact with each other.



ASTORINO Operation Manual




Select [Only X,Y,Z] in HOME/Tool Tab


Choose the Tool number to Teach from the list. 1,2 or 3 or be selected.

Switch the robot to Teach Mode and move to positions as below (this is an example, real positions might be different). After each position is reached, press SAVE Ax, where x is 1,2,3 or 4.

Teach A1.




Teach A2.




ASTORINO Operation Manual


Teach A3.




Teach A4.



Press [Calculate TOOL] button.



New calculated tool data will be saved on the SD card and displayed on the TOOL tab.




ASTORINO Operation Manual


22.2.4 Teaching the Six Base Poses

The initial points A1,2,3 & 4 should be taught as referenced in the four poses method.


For Base Pose B, teach so that contact is made between the Measuring Jig's Origin and a position 100 mm or more away from the TCP (tool center point) in the desired -Z direction of the tool.



For Base Pose C, teach so that contact is made between the Measuring Jig's Origin and a position 100 mm or more away from the TCP in the desired +Y direction of the tool.



ASTORINO Operation Manual




Select [X,Y,Z,O,A,T] in HOME/Tool Tab.


Choose the Tool number to Teach from the list. 1,2 or 3 or be selected.

Switch robot to the Teach Mode and move to positions as below (this is an example, real positions might be different). After position is reached, press SAVE Ax, where x is 1,2,3 or 4.

Teach A1.



Teach A2.




ASTORINO Operation Manual

Teach A3.




| TOOL | | WIZARD | |
|---|--|--|-------------------------------------|
| <input type="radio"/> Only X,Y,Z | <input checked="" type="radio"/> X,Y,Z,O,A,T | Tool: 1 | <input type="button" value="▼"/> |
| <input type="button" value="SAVE A1"/> | <input checked="" type="checkbox"/> | <input type="button" value="SAVE A2"/> | <input checked="" type="checkbox"/> |
| <input type="button" value="SAVE A3"/> | <input checked="" type="checkbox"/> | <input type="button" value="SAVE A4"/> | <input type="checkbox"/> ? |
| <input type="button" value="SAVE B"/> | <input type="checkbox"/> ? | <input type="button" value="SAVE C"/> | <input type="checkbox"/> ? |
| <input type="button" value="Calculate TOOL"/> | | | |

Teach A4.



| TOOL | | WIZARD | |
|---|--|--|-------------------------------------|
| <input type="radio"/> Only X,Y,Z | <input checked="" type="radio"/> X,Y,Z,O,A,T | Tool: 1 | <input type="button" value="▼"/> |
| <input type="button" value="SAVE A1"/> | <input checked="" type="checkbox"/> | <input type="button" value="SAVE A2"/> | <input checked="" type="checkbox"/> |
| <input type="button" value="SAVE A3"/> | <input checked="" type="checkbox"/> | <input type="button" value="SAVE A4"/> | <input checked="" type="checkbox"/> |
| <input type="button" value="SAVE B"/> | <input type="checkbox"/> ? | <input type="button" value="SAVE C"/> | <input type="checkbox"/> ? |
| <input type="button" value="Calculate TOOL"/> | | | |

Teach B.




| TOOL | | WIZARD | |
|---|--|--|-------------------------------------|
| <input type="radio"/> Only X,Y,Z | <input checked="" type="radio"/> X,Y,Z,O,A,T | Tool: 1 | <input type="button" value="▼"/> |
| <input type="button" value="SAVE A1"/> | <input checked="" type="checkbox"/> | <input type="button" value="SAVE A2"/> | <input checked="" type="checkbox"/> |
| <input type="button" value="SAVE A3"/> | <input checked="" type="checkbox"/> | <input type="button" value="SAVE A4"/> | <input checked="" type="checkbox"/> |
| <input type="button" value="SAVE B"/> | <input checked="" type="checkbox"/> | <input type="button" value="SAVE C"/> | <input type="checkbox"/> ? |
| <input type="button" value="Calculate TOOL"/> | | | |

ASTORINO Operation Manual


Teach C.



Press [Calculate TOOL] button.



New calculated tool data will be saved on the SD card and displayed on the TOOL tab.




23 Automatic WORK (Coordinates Data) Registration

This chapter describes operation procedures for automatic registration of Work coordinates values.

[ATTENTION]

Automatic work registration is a kind of teaching. Its usage is limited to personnel who have completed special training and are qualified for teaching or supervising robot operations.

23.1.1 Teaching the three base points



Choose the WORK number to Teach from the list. 1 or 2 or be selected.

Switch the robot to Teach Mode and move to positions as below (this is an example, real positions might be different). After each position is reached, press SAVE O, X or Y. Point O defines the beginning of coordinate system, point X defines the direction of a new X axis, point Y defines the direction of a new Y axis.

ASTORINO Operation Manual

Teach O.




Teach X.



Teach Y.




Press [Calculate Work] button.



ASTORINO Operation Manual

New calculated WORK data will be saved on the SD card and displayed on the WORK tab.



24 Auto-calibration of collision detection

[ATTENTION]

Calibration is done for a specific program, changing the program might require to repeat this procedure again!

To auto calibrate the collision detection thresholds go to the Collision change user level to 3.

Follow listed below steps:

- Switch robot to Teach or Repeat mode (calibration will be done for recently selected mode),
- Select a program for which you would like to calibrate the sensor,
- Go to Collision detection tab and click [Calibration ON/OFF]
- Run the selected program for a few cycles,
- Stop the program (Cycle off),
- Go to Collision detection tab and click [Calibration ON/OFF],
- New data will be saved to robots memory.

⚠ WARNING!


Starting the auto-calibration procedure disables collision detection during measurements! Only trained personnel should perform this procedure! Increased caution is advised!

 ASTORINO Operation Manual

25 I/O – 3,3V


The Astorino has 8 inputs and 8 outputs at 3.3V DC.

| Colours | Function |
|---------|--------------|
| Yellow | Output |
| Green | Input |
| Red | 3,3 V/DC |
| Black | Ground (GND) |



ASTORINO Operation Manual

The system normally operates in PNP switching mode (sourcing current). PNP means positive switching (mainly used in Europe and North America). A module therefore switches positive potential to its output.



The operation can be changed to NPN by using the following commands in the terminal:

- Z_OUTSOURCE 1 – SOURCE OUTPUT
- Z_OUTSOURCE 0 – SINK OUTPUT
- Z_INPULL 1 - activates pulling the inputs to 3,3V
- Z_INPULL 0 - deactivates pulling the inputs to 3,3V

! WARNING!

Each OUTPUT provides 8mA of current. Please do not exceed the limit as this may damage the motherboard.

ASTORINO Operation Manual


26 ARM INPUTS/OUTPUTS

The B version of the astorino robot is equipped with two 24V inputs and two 24V outputs (PNP) on JT3 of the arm.

In the astorino software and AS system signal numbers 57 and 58 for outputs, 1057 and 1058 for INPUTS.

The connector used is XH-2.54 6 pin female.

Refer to this table for connection the INPUTS/OUTPUTS



⚠ WARNING

Each OUTPUT provides 300mA of current. Do not exceed the limit, it might damage the Main Board.

27 MODBUS TCP

Modbus is a data communication protocol originally published by Modicon (now Schneider Electric) in 1979 for use with its programmable logic controllers (PLCs). Modbus has become a de facto standard communication protocol and is a commonly available means of connecting industrial electronic devices.




⚠️ WARNING

Astorino in Modbus Client settings does not update the register during movement!


27.1 Modbus network operating modes

Astorino can operate in two network modes. The robot can be set as a server or a client. The signal field remains the same.

- Modbus TCP Server



- Modbus TCP Client



ASTORINO Operation Manual

27.2 Modbus object types in astorino robot

The following object types may be provided by a Modbus server to a Modbus client device. The addresses are representative of the original Modicon specification. Under the current standard the address can be 0 - 65535 with the object type identified by the command used to read or write the coil or register. The Astorino robot can read and write 3x Input Registers and 3x Holding registers, that gives additional 56 inputs and 56 outputs.

astorino robot uses standard PORT: 502

astorino as Modbus Server

| Object type | Astorino function | Size | Address Space |
|------------------|-------------------|---------|---------------|
| Input register | outputs | 16 bits | 30001 – 30003 |
| Holding register | inputs | 16 bits | 40001 – 40003 |

astorino as Modbus Client


| Object type | Astorino function | Size | Address Space |
|------------------|-------------------|---------|---------------|
| Input register | inputs | 16 bits | 30001 – 30003 |
| Holding register | outputs | 16 bits | 40001 – 40003 |

ASTORINO Operation Manual

27.3 Configuration of the Ethernet port

Set the network addresses according to your PLC/HMI configuration and set Ethernet Settings to Modbus TCP.

Astorino as Modbus TCP Server




The screenshot shows the 'Ethernet' tab selected in the top navigation bar. A dropdown menu shows 'ModbusTCP Server' is selected. The 'Ethernet Settings' section contains the following IP address fields:

- IP Adress: 192.168.0.1
- Subnet Adress: 255.255.255.0
- Gateway Adress: 192.168.0.1
- DNS Adress: 192.168.0.1

Below these, the 'Modbus TCP port' is set to 502, and a 'Connected' checkbox is checked. A 'Save' button is at the bottom right. The 'Modbus TCP' logo is in the bottom left.

Astorino as Modbus TCP Client



The screenshot shows the 'Ethernet Settings' section with the 'ModbusTCP Client' dropdown selected. The network configuration fields are filled with the following values:


- IP Adress: 192.168.0.1
- Subnet Adress: 255.255.255.0
- Gateway Adress: 192.168.0.1
- DNS Adress: 192.168.0.1

Below these, the 'Modbus TCP port' is set to 502, and a 'Connected' checkbox is checked. A 'Save' button is at the bottom right. The 'Modbus TCP' logo is in the bottom left.

27.4 ASTRAADA HMI panel – example

This example shows only the configuration of the Modbus TCP communication protocol on the ASTRAADA HMI panels. For more information refer to the ASTRAADA HMI manuals. ASTRAADA HMI Panel IP is 192.168.0.100


Set correct modbus device settings in astorino app:




ASTORINO Operation Manual

Open ASTRAADA HMI CFG program and set the correct HMI panel in the options.

1. Add link.




2. Configure the link add a ModBus (Device/Slave TCP/IP).



Set IP address, timeout, retry count etc. It is suggested to set retry count to minimum of 3, and timeout to at least 3s.


ASTORINO Operation Manual



ASTORINO Operation Manual



3. Set data types

In this example Inputs and Outputs will be set as normal and dedicated Inputs/Outputs




ASTORINO Operation Manual

4. Add a new screen and configure its content.




ASTORINO Operation Manual

5. Configure the buttons to read/write particular addresses.



6. Save and write data to the HMI.

7. If the communication is working correctly, the status will be displayed on this Menu.



ASTORINO Operation Manual

8. Status of the registers is displayed on this tab. If the register Bit is on/true state then the Buttons lights up Yellow.



27.5 Using Modbus registers to read/write numeric data

For reading and writing numeric data through Modbus registers the **BITS** function can be used.

```
.PROGRAM BIT
  BITS 9,16 = 12082 ;sets a number as bits
  x = BITS(1009,16) ;reads a number from bits
.END
```

28 External Control and RTC

Astorino robot can be controlled by PC/Android/iOS/Arduino etc. achieving data transmission through certain communication protocols. The communication can be realized by USB-serial port(COM), 3.3V TLL level serial port, Ethernet TCP/IP. Please see [astorino Communication Protocol Manual] for more information.

29 Calibration

Perform calibration after assembling the robot. After calibration, the zeroing data is stored on the microSD card located on the main CPU board inside the robot base. This means that the robot does not have to be recalibrated each time the power supply is switched off.

The calibration procedure is described in the Troubleshooting manual.

30 FAQ/Troubleshooting and spare parts

Please refer to astorino Troubleshooting manual for help and list of spare parts.

31 Manufacturer information

For further questions, contact Kawasaki Robotics support.

Contact:

Kawasaki Robotics GmbH

tech-support@kawasakirobot.de

+49 (0) 2131 – 3426 – 1310

Kawasaki Robot
ASTORINO
OPERATION MANUAL

2025-09: 16th Edition


Publication: KAWASAKI Robotics GmbH

Appendix 1 – Default zeroing procedure


Astorino robot is equipped with incremental encoders, therefore after powering it up all axes must be zeroed.

This procedure is automatic and in its default configuration is described below.


JT1:



JT2:




JT3:




ASTORINO Operation Manual


JT4:



JT5:



JT6:




Appendix 2 – 3D printing parameters

For proper quality of 3D printed parts use those listed below setting:

- 5 walls
- >25% infill,
- Rectilinear infill style,
- Well dried PET-G material,
- 0.2mm layer height
- Support enabled,
- Use high quality 3d printing machine for example Prusa CORE One, Bambu X1, Creality K1 or similar.

ASTORINO Operation Manual

Appendix 3 – Name plate and serial number



Appendix 4 – PET-G material

PETG is one of the most versatile 3D printing materials, strong and easy to print. Its popularity has increased over the last years as an alternative to PLA. PETG is the PET variant used in 3D printed. The G at the end means Glycol-modified. This change affects the chemical structure, making the material more transparent, less fragile and easier to process.

PETG has very interesting properties, and its closest competitors are PLA and ABS. The main properties you should consider are the following:

- **Rigidity:** Difficulty of the material to be deformed, including stretching and bending. PLA is more rigid than PETG, being PETG and ABS almost as rigid.
- **Resistance:** PETG is generally more difficult to break than PLA and ABS. Based on technical properties, PETG is not only more resistant than ABS, but the adhesion between layers is higher, giving an overall better resistance.
- **Heat resistance:** PETG softens at 80°C, while PLA can start softening at 50°C. However, ABS has the highest heat resistance, softening at 105°C.
- **Odourless printing:** Unlike ABS, PETG does not produce an odour when printed.
- **Recyclable:** Due to its popularity, most cities have the required infrastructure to recycle PETG.

How to print PETG

Hotend temperature: PETG is usually printed at 220-250°C, and it can be printed with almost any 3D printer, including all-metal hotends or those that use an inner PTFE tube.

- **Surface temperature:** In order to print PETG, it's necessary to use a heated bed at 60-90°C. It's also recommended to add an adhesive such as paper glue to the print surface.
- **Enclosed 3D printers:** Even though it's not necessary to use enclosed 3D printers, we recommend to avoid room temperature variations.
- **Layer fan:** It's recommended to use a layer fan when printing PETG.
- **Warping:** PETG has a reduced thermal contraction, so it is not prone to warping and results in parts with good dimensional tolerances

Appendix 5 – PNP wiring


PNP stands for Positive, Negative, Positive. Also known as sourcing. On an IO Module, a PNP input, when undriven is pulled up to a high state e.g. +24V.

Most common in Europe is the ‘sinking’ type of input/output, these will be used with the PNP sensor or actuator. Less common nowadays are input cards that ‘source’, these were popular in Asia and require the NPN type of sensor in order to operate correctly.

Here's a simple way remember how to wire up a 3-wire DC PNP:

PNP = Switched Positive

“Switched” refers to which side of the controlled load (relay, small indicator, PLC input) is being switched electrically. Either the load is connected to Negative and the Positive is switched (PNP).




Appendix 6 – Teensy 4.1

Teensy 4.1 is the most powerful Arduino compatible microcontroller available today. Based on the NXP i.MX RT1062 ARM Cortex-M7 running at 600MHz with the ability to be overclocked. It is formatted into a very compact ‘teensy’ board outline for easy embedding into projects or for use with solderless breadboards. Perhaps best of all, it is compatible with the popular Arduino IDE programming environment as well as many of the existing Arduino libraries, so it is very easy to get up and running unlike many other advanced microcontrollers that are available.

The heart of the i.MX RT1060 microcontroller is an ARM Cortex-M7 CPU core that brings many powerful features to a true real-time microcontroller platform.

The Cortex-M7 is a dual-issue superscalar processor, meaning the M7 can execute two instructions per clock cycle, at 600MHz! Of course, executing two simultaneously depends upon the compiler ordering instructions and registers. Initial benchmarks have shown C++ code compiled by Arduino IDE tends to achieve two instructions per cycle about 40% to 50% of the time while performing numerically intensive work using integers and pointers.



For more information please visit PJRC webpage.

<https://www.pjrc.com/store/teensy41.html>