

FA-24SW-008

How to Apply for a neoROSET License File (Node-locked)

Apr. 17th, 2025


Kawasaki Heavy Industries, Ltd.

Robot Business Division
Precision Machinery & Robot Company


Introduction

■ How to Apply for neoROSET Node-locked License

- Node-locked license



- Floating license




[Node-locked license] How to apply (1)

① Install neoROSET

② Launch  CodeMeter Control Center from the Windows Start menu.


③ On the “CodeMeter Control Center” , select [neoROSET CmActLicense~] and click “License Update”.



※ Be careful not to select [neoROSET TRIAL] and click License Update.


【Node-locked license】 How to apply (2)

- ④ Click Next .




[Node-locked license] How to apply (3)

⑤ Select “Create license request” and click Next.




[Node-locked license] How to apply (4)

⑥ Click Commit.




[Node-locked license] How to apply (5)

⑦ The license request file has been successfully created.
Send the created file to your supplier.



[Node-locked license] How to activate license

- ① Drag and drop the license file sent by Kawasaki into the CodeMeter Control Center.
⇒ **The license is activated and neoROSET is available.**



License file

*Please whitelist the domain @global.kawasaki.com to ensure we can receive emails from this address.

世界の人々の豊かな生活と地球環境の未来に貢献する
“Global Kawasaki”